



Figure No. 7

On wide firebox boilers with engineer's cab ahead of firebox, locate gage cocks and water glass on backhead and in engineer's cab as provided for above except that "L" must be measured ahead from front of crown to center of lowest gage cocks when cocks are located in engineer's cab. When gage cocks are tapped directly into boiler, special care should be taken to measure height to lowest point of cock. If cocks are applied to separate column use reading $\frac{1}{2}$ inch higher than given in table.